Release Notes - < WinCEImagers 19>

Introduction
Description
Contents
Device Compatibility
Installation Requirements
Installation Instructions
Part Number and Release Date

Introduction

Imager Control Services (ICS) is a stand-alone Windows Control Panel application that is used for imagers and cameras, in legacy Psion products. ICS is required for some imager engines (SE4600 excluded). It includes all camera and imaging management parameters as well as the barcode options and features found in SCS (scanner Service for laser scanners).

Description

- 1. Fix an issue where a XT15 with SE4500 would occasionally not resume from suspend.
- 2. Improved edge detection for AWB
- 3. Fixed column index issue in list view structure for ICS presets
- 4. Corrected string conversion of ICS preset names on Utf8 platforms
- 5. Workaround for known AimID issues in Intermec decoder
- 6. Corrected German translation on "My Pictures" for ICS Demo App and CPL
- 7. Added safety check for sync between ICS and SCS
- 8. Fixed hang of ICS "Imager Decode" while SCS busily updating settings
- 9. Re-initialized vibrator and beeper in ICS driver for HHP imager after suspend-resume
- 10. Corrected issues in translation rules for barcode data
- 11. Reduced default minimum length of several 1D barcodes (SE4500)
- 12. Re-formatted composite decoded date to comply with SE4500 data structure

Contents

Filename	File Description
PICDXXXXXXEX190000.exe	Imager SDK
PICSXXXXCPEX190000.exe	Installer Simplified Chinese
PICSXXXXCTEX190000.exe	Installer Traditional Chinese
PICSXXXXDEEX190000.exe	Installer German
PICSXXXXENEX190000.exe	Installer English
PICSXXXXFREX190000.exe	Installer French
PICSXXXXITEX190000.exe	Installer Italian
PICSXXXXKOEX190000.exe	Installer Korean
PICSXXXXPBEX190000.exe	Installer Portuguese
PICSXXXXSIEX190000.exe	Installer Spanish
Release Notes_WinCEImagers 19.0.htm	Release note

Device Compatibility

This software release has been approved for use with the following devices.

Device	Operating System
Omnii XT15	Windows CE 6.0 or Windows Embedded Handheld 6.5
Workabout Pro 4	Windows CE 6.0 or Windows Embedded Handheld 6.5

Installation Requirements

- 1. Mobile computer listed above.
- 2. SD card and reader

Installation Instructions

- 1. Copy installer exe to SD card and insert into mobile computer.
- 2. Double click installer exe and follow installation instructions.

Part Number and Release Date

PICDXXXXXXEX190000

PICSXXXXCPEX190000

PICSXXXXCTEX190000

PICSXXXXDEEX190000

PICSXXXXENEX190000

PICSXXXXFREX190000

PICSXXXXITEX190000

PICSXXXXKOEX190000

PICSXXXXPBEX190000

PICSXXXXSIEX190000

November 4, 2015